



Thank You for Your **LUXSENSE SUPPORT!**

GETTING STARTED IS QUICK AND EASY — JUST FOLLOW THESE TWO STEPS:

I. DOWNLOAD THE LUXSENSE APP

📲 Scan one of the QR codes below to download the app or search for our app within your app store:



IOS



ANDROID

Once installed, open the app and:

1. Accept all requested permissions
2. Enter your **Registration ID** (provided with your order)
3. You'll then be taken to the main menu

II. POWER ON AND PAIR YOUR LUXSENSE SENSOR

🔌 Plug in the power adapter; the display will step through startup messages:

- “Powering up ...”
- “Sensor: [device type]”
- “LuxSense Version [x.x.x]”
- “LuxSense Device ID [Lux..]”
- “LuxSense Device Name [Name Your Sensor]”
- “Sensor can now connect to your LuxSense app”

Then, in the LuxSense app:

1. Go to Settings menu option
2. Follow the in-app instructions to pair your sensor
3. New sensors will appear as UNASSIGNED in your list
4. You'll need your valid WiFi credentials to complete setup

📞 If you need help at any point, our team is here for you.
support@luxsense.tech



LuxSense EchoGuard –

The Ultrasonic Motion Monitor



IMPORTANT SETUP INSTRUCTIONS FOR ECHOGUARD

To ensure optimal performance, place your EchoGuard device in its intended location before powering it on. EchoGuard will determine maximum distance reading to use as a calibration target.



CALIBRATION PERIOD:

EchoGuard calibrates automatically within the first few seconds after power-up. Please avoid moving the sensor, repositioning it, standing in front of it during this time. EchoGuard will display the determined maximum reading.



NOTIFICATION BEHAVIOR:

You'll receive a notification when EchoGuard detects a distance reading between the fixed minimum distance of ~12 inches and the calibration maximum.



TO RECALIBRATE:

Simply restart the device.
